

Care Instructions

Sissi Series



Lifely*

Product Code
SISI-RUG-160
SISI-RUG-200
SISI-RUG-240

Dimensions(W x D)
1600x2300mm
2000x2900mm
2400x3300mm

Important

Please read through instruction carefully
Before assembly and keep for future reference.

For our full catalogue of assembly instructions,
Visit: lifely.com.au/assembly.

Important Tips and Maintenance



AFTER OPENING

Re-roll your rug pile out for 24 hours to reduce curling. Regularly turn to ensure even wear.



WE RECOMMEND

A slip-resistant mat will help prevent slipping.



SETTLING IN

A small amount of fibre loss is normal. Don't pull loose fibres, just trim with scissors.



EASY CARE

Blot spills immediately with a clean, dry white cloth. Do not rub.



COLOUR CARE

If using cleaning products on your rug, test them first on an inconspicuous area for colour changes.



BE AWARE

Do not leave young children unsupervised.

Great job. You're done!

Don't forget to share how it looks in
your space and tag us on Instagram.

@lifelyhome#homewithlifely!