







RS1L-A

安装方法/  
Installation method





二合一/2 in 1



塑料螺母 Plastic nut

阀门开关(下压为开)  
Valve switch (press down to open)



三节滚珠导轨-14"  
Three Section Ball Guide-14"

