

LINSY 林氏家居

五金表/Hardware list

部件表/Parts List

安装示意图/Assembly Instruction

产品名称 Model NO.





LH183J1-A边几

产品规格 Specification

710*280*518mmH


安装工具 Tool

安装人数 Installer



(A) * 16

白攻螺丝-
(M4*16mm)彩锌
Self tapping
screw



(B) * 4

万向轮-38mmH
Universal wheel

编号NO.

名称Name

规格 (mm)
Specification

数量QTY

材质Material

①

整装边几
Side table

710*280*480

1

实木 wood

②

面板玻璃
Panel glass

593*238*5

1

玻璃 glass

③

层板玻璃
Laminated glass

280*183*5

1

玻璃 glass

LH183J1-A边几


安装方法/
Installation method



(A)* 16




(B)* 4



1

整装边几倒置，安装滑轮

Invert the assembled side table and install the casters..




2

分别放入面板玻璃、侧板玻璃。

Place the panel glass and side panel glass separately.

3



安装完成.

Installation Complete